



Cut connector off of blower wires.[A]  
Connect black to black.(Power In)[B]  
White and blue wires get grounded.[C]  
White gang plug on harness plugs into module.[D]  
Black gang plug on harness plugs into water valve[E]

