


Fig. 1



Please call or email RigMaster Technical Support for any questions. Thank you.

#### RIGMASTER POWER INTERNATIONAL LTD.

1320 Ellesmere Road, Unit 1, Toronto, ON, M1P 2X9, Canada Tel: 416-201-0040 ● Toll Free: 1-800-249-6222 ● Fax: 416-293-5104

 $\textbf{Website:} \ \underline{\textbf{www.rigmasterpower.com}} \bullet \textbf{Email:} \ \underline{\textbf{rigmastertechsupport@rigmasterpower.com}}$ 



### **Technical Service Bulletin**

RMI-TSB-001-20170701

# NEW Duel Blower Control Module Kits For ALL APU's With Dual Blowers

The update is intended to improve the operations on ALL units by replacing the Dual Blower Control Module that was provided or installed on our APU's.

KL7-023	Dual Blower Control Module (Used with BOTH Kits)
KL7-023K	Dual Blower Control Module Kit without Heat
KL7-026K	Dual Blower Control Module Kit with Heat

#### KL7-023K – Dual Blower Control Module Kit WITHOUT HEAT

Part No.	Description	Quantity
KL7-023	Dual Blower Control Module	1
KL7-023-01	Dual Blower Control Module Harness (NO HEAT)	1

#### KL7-026K - Dual Blower Control Module Kit WITH HEAT

Part No.	Description	Quantity
KL7-023	Dual Blower Control Module	1
KL7-026-01	Dual Blower Control Module Harness (HEAT)	1

NOTE: <u>KL7-023</u> IS THE MODULE ITSELF. AFTER THIS UPDATE, THIS IS THE COMPONANT THAT WILL BE REPLACED IF BLOWER FUNTIONS WERE DIAGNOSED/TROUBLESHOT TO BEING THE ROOT CAUSE OF FAILURE.



No fixed wiring harness

<u>Changes made to Dual Blower</u> Control Module.

Fuse built in to Module

KL7-023

## DUAL BLOWER CONTROL MODULE HARNESS WITHOUT HEAT (KL7-023-01)

<u>This wiring harness will replace the pre-existing harness</u> that was attached to the previous version of the **Dual Blower Control Module**. Once this harness has been installed it will be fixed to the HVAC Box and will **ONLY** need to be replaced if there is any type of damage to the harness itself.

### KL7-023-01 Main J2 Main Power Fan Ground wire to Connector Harness Speed into for Dual Dual (Signal and Blower Blower Blower wires Ground Control Control from PCM Control wires to Module to Blower Dual Module Control Blower Module)

# DUAL BLOWER CONTROL MODULE HARNESS WITH HEAT (KL7-026-01)

<u>This wiring harness will replace the pre-existing harness</u> that was attached to the previous version of the **Dual Blower Control Module**. Once this harness has been installed it will be fixed to the HVAC Box and will **ONLY** need to be replaced if there is any type of damage to the harness itself.

